

**Addonics Technologies, Inc.**  
**ADST203 (Combo USB 2.0, Firewire and Serial ATA Host Controller)**

**Features**

- Add 4 USB 2.0, 3 Firewire (IEEE 1394) ports and 2 Serial ATA ports to Desktop PC via one PCI slot
- The two Serial ATA ports can be configure to provide RAID 0 for high throughput or RAID 1 for fault tolerance storage system
- Plug and Play in Windows 98SE, Me, 2000 and XP
- Great for any USB, Firewire, Serial ATA Storage Devices, Digital video camcorder, scanners, printers, or any USB or Firewire peripheral devices

**Package Contents**

- One Controller card
- Driver Disc
- This quick user guide

**System Requirements**

- USB2.0 and Firewire (Windows 98SE, Me, 2000, XP and Mac OS X or greater (at USB 1.1 speed only)
- Serial ATA (DOS, Windows 95, NT 4.0, 98SE, Me, 2000 and XP



**Driver Installation Guide**

**Firewire**

**Windows 98SE, Me, 2000 and XP**

1. Turn computer ON. When Windows boots up, "A New Hardware Found" pops on the screen and the Texas Instrument OHCI Compliant IEEE 1394 Host Controller is identified.
2. At the "Add New Hardware Wizard Window, click "Next"
3. Choose "Select for the best driver for your devices", and click "Next"

4. Insert the Windows 98se CD-ROM and check the "CD-ROM" option. Click "Next"
5. Choose "The updated driver (Recommended)", click "Next", then "Next" again.  
Note: if windows prompt you for the Windows CD-ROM again, type in D:\win98 and click "OK". (Assuming "D" is the CD-ROM drive letter)
6. Click "Finish" to complete the installations.

**Note: Firewire drivers are built in on the OS under Windows Me, 2000 and XP.**

**USB2.0**

**Windows 98SE, Me, 2000 and XP**

- Ø When Windows ask for the USB2.0 Driver, just point the wizard to the Driver Disc (**from your CDROM Drive**) to search for the driver, install the USB2.0 driver and that's it.
- Ø Click continue anyway for the Digital signature warning under XP.

**Serial ATA**

**Windows 98SE, Me, 2000 and XP**

- Ø When Windows ask for the SATA Driver, just point the wizard to the Driver Disc (**from your CDROM Drive**) to search for the driver, install the USB2.0 driver and that's it.
- Ø Click continue anyway for the Digital signature warning under XP.

**Contact Information**

Addonics Technologies  
2466 Kruse Drive  
San Jose CA, 95131  
Phone: 408-433-3899  
Fax: 408-433-3898  
Internet: <http://www.addonics.com>

**Technical Support**

Phone: 408-433-3855  
Email: [Techinfo@addonics.com](mailto:Techinfo@addonics.com)

Note: Specifications subject to change without notice.

Copyright © 1998 - 2005 Addonics Technologies, Inc. All Rights Reserved.