

# ADDONICS TECHNOLOGIES


Model: ADSAESA

---

## Installation Guide

---

### Angled View



### ADSAESA Windows Driver Installation

Note: If you are only configuring independent drives using the host controller all you need to install is the driver. This controller connects to a PCI slot.

1. Connect the SATA host controller to an available PCI slot.
2. Turn computer ON. When Windows boots up, the "Found New Hardware Wizard" pops on the screen and the Silicon Image Sil 3512 SoftRaid Controller is identified.
3. Place the Driver Disk on your optical drive. Select automatically look for driver on the wizard.
4. Wait while the wizard installs the software...
5. After driver installation, it is recommended to restart your system.

### SATARAID Management Utility Installation

Note: If you are configuring RAID sets, in addition to installing the driver, you need to install the SATARAID Management Utility to configure and monitor the RAID sets. Install the utility from the CD that came with your package **FIRST** before installing the SATA host controller.

1. Turn computer ON. Insert Driver Disk into CDROM.
2. The Addonics Technologies Driver Disk window pops up.
3. Select SATA RAID Utilities. To download the utility select model of the controller from the list.
4. Extract the files into your system.
5. Install VC2005 Redistributables
  - i. For 32-bit platforms, execute vcredist\_x86.exe
  - ii. For 64-bit platforms, execute vcredist\_x64.exe
6. Install .Net Framework 2.0
  - i. For Windows 2000/XP/2003, Execute dotnetfx.exe
  - ii. For Windows Vista, skip this step.
7. Install SATARaid Utility 1.0.0.26
  - i. Execute InstallSATARaid.exe and follow the on screen directions.
8. Follow the Windows driver installation.

The SATARAID Utility Manual can found in the Driver Disk under User Guides or can be downloaded from [http://www.addonics.com/support/user\\_guides/host\\_controller/SATARaid-Manual\\_v1.03.pdf](http://www.addonics.com/support/user_guides/host_controller/SATARaid-Manual_v1.03.pdf)

### Confirming Serial ATA Driver Installation

1. Right click the My Computer icon and select Properties.
2. Click Device Manager in the Menu Tree.
3. Click the "+" sign in front of SCSI and RAID Controllers. You should see **Silicon Image Sil 3512 SoftRaid Controller**.

---

## TECHNICAL SUPPORT

---

Email: <http://www.addonics.com/sales/query/>  
Internet: <http://www.addonics.com>

Technical Support (8:30 am to 6:00 pm PST)  
Phone: 408 453-6212  
Email: <http://www.addonics.com/support/query/>